










3 1/2 (S2-312) 盤面電表

編號



範圍調整 Span adjustment.  
 如果是4~20mA,1~5V 輸入  
 歸零調整.  
 If 4~20mA,1~5V Input,  
 Zero adjustment.

段數 Step No.	跳線 (No.) Jumper	顯示範圍 Display Range
1.	 [2,4]	1600~2000
2.	 [1,2]	1200~1800
3.	 [1,3]	900~1400
4.	 [3,4]	800~1100
5.	 [4,6]	650~900
6.	 [5,6]	450~650
7.	 [6,8]	300~450
8.	 [3,5]	200~300

跳線 Jumper	小數點顯示 Decimal Point Display
